



Please Read The Entire Installation Manual BEFORE Installing Your Camper Package!

We recommend watching the Camper Installation video on our website at TopperEZLift.com/videos If you need additional support call us toll free at 1-877-876-2576



Included In The Kit

- 4 Canvas Pieces
- Driver Side Canvas
- Passenger Side Canvas
- Cab (Front) Side Canvas
- Weekender/Contractor (Back) Canvas

Tools Needed

- Scissors
- Utility Knife
- Rubbing Alcohol
- Phillips Head Bit
- Drill
- Tent Pole (Weekender only)
- 111" Awning tent pole
- (2x) 35" Vertical tent pole
- Adhesive Backed Velcro
- Self-Tapping Screws (x6)

-Clean side of truck rail with rubbing alcohol where adhesive backed velcro will go



-Clean top side of topper rail with rubbing alcohol where adhesive backed velcro will go



-Apply 3M adhesive promoter

-If you have a carpeted topper you can skip applying velcro to topper

-Apply adhesive backed velcro on truck rail



- At the ends of the velcro just placed cut an "x" with a utility knife and screw in a self-tapping screw at those "x's"

-This will ensure the velcro does not peel up at corners over time

-There will be 2 self-tapping screws for the Driver Side, 2 for Passenger Side and 2 for Cab (front) Side canvas

-Start with Cab Side canvas
-2 inch velcro indicates the top
-1 inch velcro indicates the bottom



-Start by lining up the bottom 1 inch velcro on canvas to the adhesive velcro placed on the truck



-Make sure canvas is centered

-Pull the canvas up to the topper and attach the 2 inch velcro on the canvas to the adhesive velcro on the topper. Start in center and work out towards corners



-Now put on the Driver Side Canvas. With the 2 inch velcro on top and the window on the right side indicates it is the Driver Side canvas. The additional velcro strips on the left are for universal attachment across different truck bed lengths. These will line up with the Cab Side Canvas

-Line up the bottom 1 inch velcro of the canvas with the adhesive velcro on truck rail

-Start at tailgate and line up back edge of Driver Side canvas with tailgate bump out



-At the cab one of the driver side canvas velcro strips will line up with the Cab Side velcro

-You may have to adjust the canvas backward or forward to get the ideal fit

-Now pull the canvas up to the topper and attach the 2 inch velcro on the canvas to the adhesive backed velcro on the topper



-We do not recommend cutting off the extra material in case you choose to put this system on a different truck in the future



-Now we will put on the Passenger Side Canvas. With the 2 inch velcro on top and the window on the left side indicates it is the Passenger Side canvas. The additional velcro strips on the right are for universal attachment across different truck bed lengths. These will line up at the Cab Side Canvas

-Repeat the steps from page 2 and page 3 to install the Passenger Side canvas



-You may have to adjust the canvas backward or forward to get the ideal fit

Installing The Weekender Back



-Line up corners evenly on Weekender canvas as best you can



-Place adhesive backed velcro where Weekender canvas meets the truck bed
-Alternatively you can attach it to your bedrug or carpet if you have one installed



-Use the loops on the sides of the Weekender canvas to hold down Weekender canvas to or around tailgate



-Match the side walls of the Weekender canvas to the velcro of the Driver and Passenger side canvas



-There are tuck flaps at the top of the Weekender canvas that can be used to stuff into gaps at the back of some toppers



Non-Carpeted Topper

-You Must Carpet the portion of your topper where the velcro on your camper package will meet.

-Visit our website or contact us for options to carpet your topper.



-Grab the ends of the tent pole and make a half moon shape. Place one end of the tent pole in the door of the Weekender canvas

-Now place the other end of the tent pole in the opposite side of the Weekender canvas door



-Insert the ends of the tent poles into the pockets inside the Weekender canvas located on the side walls near the topper



-Push the tent pole up into the canvas



-Attach tent pole to velcro loops starting at center

8

Campsite to Campsite!

-Fold up corners of Weekender canvas on tailgate to keep them from getting pinched by the tailgate.

-Lower topper and close back window

-Alternatively you can take off the Canvas completely. You can also take off the sides as well.



Home for the Weekend

-Bring the topper down until there is only a few inches left to go

-Go around truck and tuck canvas in and up so it does not get pinched by the topper. They will form a memory over time but it is good practice to always check

-Now you can bring the topper down all of the way

-unzip bottom of Weekender from its top. Fold up Bottom portion of canvas and store it.

-Roll up top of canvas to topper using the velcro loops at topper to hold canvas in place.

-Close tailgate and topper window.



10

Installing the Contractor Back

-The Contractor Back attaches the same way the weekender Back is attached. Refer to page 6 for how to install bottom velcro. Line up the top of the Contractor Back with the carpet at the top of your topper making sure the Contractor Back is centered from side to side. Match the side walls of the Contractor Back to the velcro of the Driver and Passenger side canvases. The 2 corners at bottom of Contractor Back may need to be folded over each other for a better fit.

-When taveleing the Contractor can be left on, be cautious not to pinch canvas when shutting tailgate. You can also unzip the two outside zippers and roll up Contractor using the velcro loops to hold it in place.

-Alternitively you can remove the whole Contractor back and store untill needed.

11



12



13

Thank You
For Purchasing The



Camper Package

If you need additional support call us toll free at 1-877-876-2576

LIMITS LIFTED

14

3M Adhesive Promoter *USE GLOVES WHEN HANDLING ADHESIVE PROMOTOR*

Surface Preparation

The bonding surface should be clean and dry. Contaminated surfaces should be cleaned with an untreated, lint-free cloth and General Purpose Adhesive Cleaner. Follow this by wiping with another untreated, lint-free cloth and isopropyl alcohol.

Application Procedure

3M Adhesion Promoter is supplied in an easy-to-use sponge applicator packet. The liquid contents of the packet should be completely used as soon as possible after opening. Hold packet upright and avoid squeezing an opened packet to prevent spillage of liquid contents. The packet can be opened by tearing across the top of the packet at the notches. This will expose the sponge applicator. Do not remove the sponge or squeeze a freshly opened packet. Handling the bottom section of the packet should enable application of 3M adhesion promoter with no mess. Apply a thin, uniform coating to the bonding surface, using the minimum amount that will fully coat the surface. Apply promoter only to areas that will be fully covered with tape. Although drying times may vary due to temperature and/or humidity, a drying time of 30-90 seconds is typical. The primer should be dry before applying tape. For best results, apply tape immediately after primer application or no more than one hour after primer application. Be sure the primed surface remains free from contaminants prior to tape application.

Clean-Up

3M adhesion promoter can be cleaned up with methylethyl ketone (MEK) or acetone solvents (be careful with solvents on plastics). Vigorous scrubbing may be required.